



Industrial Manufacturing of Glass Ampules

with digital DIAS Pyrometers **PYROSPOT**





Pyrometer in the manufacturing process of glass ampoules





lass ampoules in medical and cosmetic industries serve mainly as containers for the respective products. They are also used as thermal Irelease element in fire detection systems in sprinkler systems and other temperature-controlled release mechanisms. In the manufacturing of these glass ampoules a finished glass raw body is heated and then reshaped to the respetive form. These usually full automated processes are proceeding in a horizontal rotating table with several gas burners. The ampoules are heated by the burner to a certain temperature that is crucial for the further processing.

An important part in the process control is to capture the temperatures exactly and quickly. Temperature measurement devices used for this purpose need to be quick, exact and especially unaffected when they are measuring through the gas burner.

The particular DIAS pyrometer PYROSPOT DT 40F and DT 44F offer exactly these features. With measurement ranges between 300 °C and 2500 °C, mutable optical proportions and fast acquisiton times from 10 ms, the pyrometers measure through the burner flame to the glass surface.

For extremely small ampoules or very fast production processes the high-end pyrometer PYROSPOT DPE 10 MF kann be used. This pyrometers measures in ranges between 50 °C and 2500 °C with a acquistion time of only 1.5 ms and can realize measuring fields smaller than 1 mm. The burner flame has no influence on the measurement.

All pyrometers have a standard analoge output available or a digital interface for integration in the process control.



Picture credits: ", Pharmazeutische Flamerdichtung ampules" Copyright by Isreal Melendez Jr., Fully automatic filling and sealing machine for the production of medicines in ampules" Copyright by Nikolaj Kondratenko, ", health care / medical concept: isolated set of ampules on white background" by studioVin. 2013. Used with a licence from shutterstock de



echnische Änderungen

We are certified for many years according to ISO 9001

Phone: +49 351 896 74-0 Fax: +49 351 896 74-99 E-Mail: info@dias-infrared.de Web: www.dias-infrared.com

DIAS Infrared GmbH Pforzheimer Straße 21 01189 Dresden Germany